



Wireless Modes How-To

Modes	Description
Trip	sends arrival and departure messages for approx 300 events then automatically switches to Endurance Mode.
Endurance	25-hour daily heartbeat message only - will continue this way indefinitely until the battery is depleted. Can be switched back to Trip Mode or changed to Repo Mode as needed
Repo	sends arrival and departure messages AND 2-minute interval breadcrumb messages while moving for approx 300 events then automatically returns to Endurance Mode.

How to Update Mode:

When logging in to your account, it will bring you to a map of the United States. On the left side of the page, you will see your list of devices. Click on the device you are working with. A white box will appear at the bottom of the screen. Along the very bottom right, you will see **SET MODE**. Click on this button and another box will appear where you will be able to update the mode your device is in during the next time it reports to the system.

Important notes:

When changing the mode, the system will queue up the command and then change modes the next time it reports in.

It can take up to 25 hours for the device to update its reporting scheme (when it is in Endurance mode)

The more frequently the device reports in, the faster the battery life is consumed.